




Machine	Explode	Code	Description
Thor Burner / Freestanding Oven	1		Door Assembly for GH100-P GH100-N GE542-P GE542-N
Thor Burner / Freestanding Oven	1		Door Assembly for GH101-P GH101-N GH102-P GH102-N GE543-P GE543-N GE544-P GE544-N
Thor Burner / Freestanding Oven	2	AF699	L-shaped connector for GH100-P GH100-N GH101-P GH101-N GH102-P GH102-N GE542-P GE542-N GE543-P GE543-N GE544-P GE544-N
Thor Burner / Freestanding Oven	3	AF280	Orifice/Main burner injector for GH100-P GE542-P (oven)
Thor Burner / Freestanding Oven	3	AF778	Orifice/Main burner injector for GH100-P GH101-P GH102-P GE542-P GE543-P GE544-P
Thor Burner / Freestanding Oven	3	AF779	Orifice/Main burner injector for GH100-N GH101-N GH102-N GE542-N GE543-N GE544-N
Thor Burner / Freestanding Oven	4	AF305	Pilot Pipe Assembly - Oven for GH100-P GH100-N GH101-P GH101-N GH102-P GH102-N GE542-P GE542-N GE543-P GE543-N GE544-P GE544-N
Thor Burner / Freestanding Oven	5	AF645	Piezo Igniter for for GH100-P GH100-N GH101-P GH101-N GH102-P GH102-N GE542-P GE542-N GE543-P GE543-N GE544-P GE544-N
Thor Burner / Freestanding Oven	6	AF266	Adjustable Foot for GH100-P GH100-N GH101-P GH101-N GH102-P GH102-N GE542-P GE542-N GE543-P GE543-N GE544-P GE544-N
Thor Burner / Freestanding Oven	7	AF286	(Oven) Pilot Rack for GH100-P GH100-N GH101-P GH101-N GH102-P GH102-N GE542-P GE542-N GE543-P GE543-N GE544-P GE544-N
Thor Burner / Freestanding Oven	7	AF276	ODS/FDS-Injector(0.01" for LPG) for GH100-P GH101-P GH102-P GE542-P GE543-P GE544-P
Thor Burner / Freestanding Oven	7	AF277	ODS/FDS-Injector(0.018" for NG) for GH100-N GH101-N GH102-N GE542-N GE543-N GE544-N
Thor Burner / Freestanding Oven	8	AG671	U Burner Assembly(OVEN) for GH100-P GH100-N GH101-P GH101-N GH102-P GH102-N GE542-P GE542-N GE543-P GE543-N GE544-P GE544-N
Thor Burner / Freestanding Oven	8	AF295	U Burner Assembly(Griddle) for GH102-P GH102-N GE542-P GE542-N GE543-P GE543-N GE544-P GE544-N
Thor Burner / Freestanding Oven	9	AF296	Pivoting Plate for GH100-P GH100-N GH101-P GH101-N GH102-P GH102-N GE542-P GE542-N GE543-P GE543-N GE544-P GE544-N
Thor Burner / Freestanding Oven	10	AF980	Door Spring for GH100-P GH100-N GE542-P GE542-N
Thor Burner / Freestanding Oven	10	AF260	Door Spring for GH101-P GH101-N GH102-P GH102-N GE543-P GE543-N GE544-P GE544-N
Thor Burner / Freestanding Oven	11	AF981	Oven Shelf for GH100-P GH100-N GE542-P GE542-N
Thor Burner / Freestanding Oven	11	AF984	Oven Shelf for GH101-P GH101-N GH102-P GH102-N GE543-P GE543-N GE544-P GE544-N
Thor Burner / Freestanding Oven	12	AF269	Dial for GH100-P GH100-N GH101-P GH101-N GH102-P GH102-N GE542-P GE542-N GE543-P GE543-N GE544-P GE544-N
Thor Burner / Freestanding Oven	13		Manifold Assembly for GH100-P GH100-N
Thor Burner / Freestanding Oven	13		Manifold Assembly for GH101-P GH101-N

Thor Burner / Freestanding Oven	13		Manifold Assembly for GH102-P GH102-N
Thor Burner / Freestanding Oven	13		Manifold Assembly for GE542-P GE542-N
Thor Burner / Freestanding Oven	13		Manifold Assembly for GE543-P GE543-N
Thor Burner / Freestanding Oven	13		Manifold Assembly for GE544-P GE544-N
Thor Burner / Freestanding Oven	14	AF298	Pilot Pipe Assembly - Right for GH102-P GH102-N GE542-P GE542-N GE543-P GE543-N GE544-P GE544-N
Thor Burner / Freestanding Oven	*	AF300	Pilot Pipe Assembly - Left for GE542-P GE542-N GE544-P GE544-N
Thor Burner / Freestanding Oven	15	AF285	Flame Device System for GH102-P GH102-N GE542-P GE542-N GE543-P GE543-N GE544-P GE544-N
Thor Burner / Freestanding Oven	15	AF272	ODS/FDS Injector-0.2 for GH102-P GE542-P GE543-P GE544-P
Thor Burner / Freestanding Oven	15	AF273	ODS/FDS Injector-0.4 for GH102-N GE542-N GE543-N GE544-N
Thor Burner / Freestanding Oven	16	AH367	Drip Tray Assembly for GH102-P GH102-N GE542-P GE542-N GE543-P GE543-N GE544-P GE544-N
Thor Burner / Freestanding Oven	17	AF271	Safety Gas Valve for GH100-P GH100-N GH101-P GH101-N GH102-P GH102-N GE542-P GE542-N GE543-P GE543-N GE544-P GE544-N
Thor Burner / Freestanding Oven	18	AF299	Main Pipe Assembly - Right for GH102-P GH102-N GE542-P GE542-N GE543-P GE543-N GE544-P GE544-N
Thor Burner / Freestanding Oven	19		Tray for GH100-P GH100-N
Thor Burner / Freestanding Oven	19		Tray for GH101-P GH101-N
Thor Burner / Freestanding Oven	19		Tray for GH102-P GH102-N
Thor Burner / Freestanding Oven	19		Tray for GE543-P GE543-N
Thor Burner / Freestanding Oven	20		Griddle Plate Assembly for GH102-P GH102-N
Thor Burner / Freestanding Oven	20		Griddle Plate Assembly for GE542-P GE542-N
Thor Burner / Freestanding Oven	20		Griddle Plate Assembly for GE543-P GE543-N
Thor Burner / Freestanding Oven	20		Griddle Plate Assembly for GE544-P GE544-N
Thor Burner / Freestanding Oven	21		Flue Assembly for GH100-P GH100-N GE542-P GE542-N
Thor Burner / Freestanding Oven	21	AH363	Flue Assembly for GH101-P GH101-N GH102-P GH102-N GE543-P GE543-N
Thor Burner / Freestanding Oven	22	AF281	Regulator for GH100-P GH100-N GH101-P GH101-N GH102-P GH102-N GE542-P GE542-N GE543-P GE543-N GE544-P GE544-N
Thor Burner / Freestanding Oven	23		Trivet for GH100-P GH100-N GH101-P GH101-N GH102-P GH102-N GE543-P GE543-N
Thor Burner / Freestanding Oven	24	AF267	Burner for GH100-P GH100-N GH101-P GH101-N GH102-P GH102-N GE543-P GE543-N
Thor Burner / Freestanding Oven	25	AF284	Flame Device System - Rear for GH100-P GH100-N GH101-P GH101-N GH102-P GH102-N GE543-P GE543-N
Thor Burner / Freestanding Oven	25	AF272	ODS/FDS Injector-0.2 for LPG for GH100-P GH101-P GH102-P GE543-P
Thor Burner / Freestanding Oven	25	AF273	ODS/FDS Injector-0.4 for NG for GH100-N GH101-N GH102-N GE543-N
Thor Burner / Freestanding Oven	26	AF288	Main Pipe - Rear Assembly for GH100-P GH100-N GH101-P GH101-N GH102-P GH102-N GE543-P GE543-N
Thor Burner / Freestanding Oven	27	AF291	Pilot Pipe - Rear Assembly for GH100-P GH100-N GH101-P GH101-N GH102-P GH102-N GE543-P GE543-N

Thor Burner / Freestanding Oven	28	AF283	Flame Device System - Front for GH100-P GH100-N GH101-P GH101-N GH102-P GH102-N GE543-P GE543-N
Thor Burner / Freestanding Oven	28	AF272	FDS Injector-0.2 (for LPG) for GH100-P GH101-P GH102-P GE543-P
Thor Burner / Freestanding Oven	28	AF273	FDS Injector-0.4 (for NG) GH100-N GH101-N GH102-N GE543-N
Thor Burner / Freestanding Oven	29	AF290	Pilot Pipe - Front Assembly for GH100-P GH100-N GH101-P GH101-N GH102-P GH102-N GE543-P GE543-N
Thor Burner / Freestanding Oven	30	AF289	Main Pipe - Front Assembly for GH100-P GH100-N GH101-P GH101-N GH102-P GH102-N GE543-P GE543-N
Thor Burner / Freestanding Oven	31	AF301	Main pipe Connection for GH100-P GH100-N
Thor Burner / Freestanding Oven	31	AF304	Main pipe Connection for GH101-P GH101-N GH102-P GH102-N
Thor Burner / Freestanding Oven	31		Main pipe Connection for GE542-P GE542-N
Thor Burner / Freestanding Oven	31		Main pipe Connection for GE543-P GE543-N GE544-P GE544-N
Thor Burner / Freestanding Oven	32	AF302	Pilot Pipe Connection for GH100-P GH100-N
Thor Burner / Freestanding Oven	32	AF303	Pilot Pipe Connec for GH101-P GH101-N GH102-P GH102-N
Thor Burner / Freestanding Oven	32		Pilot Pipe Connec for GE542-P GE542-N
Thor Burner / Freestanding Oven	32		Pilot Pipe Connec for GE543-P GE543-N GE544-P GE544-N
Thor Burner / Freestanding Oven	33	AF275	Thermostat Valve(oven) for GH100-P GH100-N GH101-P GH101-N GH102-P GH102-N GE542-P GE542-N GE543-P GE543-N GE544-P GE544-N
Thor Burner / Freestanding Oven	34	AF282	Dial for GH100-P GH100-N GH101-P GH101-N GH102-P GH102-N GE542-P GE542-N GE543-P GE543-N GE544-P GE544-N
Thor Burner / Freestanding Oven	35	AF297	Door Hinge for GH100-P GH100-N GH101-P GH101-N GH102-P GH102-N GE542-P GE542-N GE543-P GE543-N GE544-P GE544-N
Thor Burner / Freestanding Oven	36		Main pipe Connection Assembly for GH100-P GH100-N GE542-P GE542-N
Thor Burner / Freestanding Oven	36	AH366	Main pipe Connection Assembly for GH101-P GH101-N GH102-P GH102-N GE543-P GE543-N GE544-P GE544-N
Thor Burner / Freestanding Oven	37		Pilot Pipe Connection Assembly for GH100-P GH100-N GE542-P GE542-N
Thor Burner / Freestanding Oven	37		Pilot Pipe Connection Assembly for GH101-P GH101-N GH102-P GH102-N GE543-P GE543-N GE544-P GE544-N
Thor Burner / Freestanding Oven	N/A		Rear panel for GH101-P GH101-N GH102-P GH102-N GE543-P GE543-N GE544-P GE544-N
Thor Burner / Freestanding Oven	N/A	AF264	Right Connect wire for GH100-P GH100-N GH101-P GH101-N GH102-P GH102-N
Thor Burner / Freestanding Oven	N/A		Left Connect wire for GH100-P GH100-N GH101-P GH101-N GH102-P GH102-N
Thor Burner / Freestanding Oven	N/A		Castor for oven (One piece), with brake
Thor Burner / Freestanding Oven	N/A	AF766	Castors for oven (One set 2pcs), with brake
Thor Burner / Freestanding Oven	N/A		Castor for oven without brake (One piece)
Thor Burner / Freestanding Oven	N/A	AF763	Castors for oven without brake (One set 2pcs)

Thor Burner / Freestanding Oven	N/A	AF798	Oven Thermocouple for GH100-P GH100-N GH101-P GH101-N GH102-P GH102-N GE542-P GE542-N GE543-P GE543-N GE544-P GE544-N
Thor Burner / Freestanding Oven	N/A	AF796	Front row open burner Thermocouple for GH100-P GH100-N GH101-P GH101-N GH102-P GH102-N
Thor Burner / Freestanding Oven	N/A	AF797	Back row open burner Thermocouple for GH100-P GH100-N GH101-P GH101-N GH102-P GH102-N
Thor Burner / Freestanding Oven	N/A	AF261	Thor Spring for GH100-P GH100-N
Thor Burner / Freestanding Oven	N/A	AF292	Thor Handle for GH100-P GH100-N
Thor Burner / Freestanding Oven	N/A	AF263	Thor Handle for GH101-P GH102-P GH101-N GH102-N
Thor Burner / Freestanding Oven	N/A	AH368	Orifice fix for GH102-P GH102-N
Thor Burner / Freestanding Oven	N/A	AF381	Conversion kits for GH100-P (-P to -N)
Thor Burner / Freestanding Oven	N/A	AF380	Conversion kits for GH100-N (-N to -P)
Thor Burner / Freestanding Oven	N/A	AF383	Conversion kits for GH101-P (-P to -N)
Thor Burner / Freestanding Oven	N/A	AF382	Conversion kits for GH101-N (-N to -P)
Thor Burner / Freestanding Oven	N/A	AF385	Conversion kits for GH102-P (-P to -N)
Thor Burner / Freestanding Oven	N/A	AF384	Conversion kits for GH102-N (-N to -P)
Thor Burner / Freestanding Oven	N/A		Conversion kits for GE542-P (-P to -N)
Thor Burner / Freestanding Oven	N/A		Conversion kits for GE542-N (-N to -P)
Thor Burner / Freestanding Oven	N/A		Conversion kits for GE543-P (-P to -N)
Thor Burner / Freestanding Oven	N/A	AH353	Conversion kits for GE543-N (-N to -P)
Thor Burner / Freestanding Oven	N/A	AH355	Conversion kits for GE544-P (-P to -N)
Thor Burner / Freestanding Oven	N/A	AH354	Conversion kits for GE544-N (-N to -P)
Thor Burner / Freestanding Oven	N/A	AG180	Pilot cover for GH100-P GH100-N GH101-P GH101-N GH102-P GH102-N GE543-P GE543-N